

ACCESSORIES

Q-Insert

4 Stroke

Q Rubber Grommet

Q insert (with bolt)

Q kit

Product Part number: DEPA4008

Product Part number: DEPA4009

Product Part number: DEPA4010



[Click here for Q-insert video](#)

Q-Insert kit

This Q-Insert kit consists of everything you need to fit the Q Insert to your DEP Silencer. It has been designed as a quick and easy way for you to reduce the decibel level on your DEP Silencer if being used in a noise-sensitive area. The Q Inserts will reduce the noise level by two DB on most models.

Kit Content

- Q-Insert
- Fixing bolt
- 5.5mm Drill
- 12mm Drill
- Rubber bung

Q-Insert Fitting

1. Position the Q-Insert into the silencer outlet.
2. Using the bolt supplied secure the Q-Insert
3. Insert the rubber bung

Installing the Q-Insert

4. Mark 19mm from end face of cap (see diagram)
5. Using 5.5mm drill provided drill pilot hole at 90° to the cap
6. Using 12mm drill provided drill hole at 90° to cap
7. Drill 5.5mm hole at 90° to the deflector tube
8. Remove any filings
9. Position the Q-Insert into the silencer out let
10. Using the bolt supplied secure the Q-Insert
11. Insert the rubber bung

